

USB Card Readers

CR20E



• Read 125K proximity card number, USB interface

CR20M



• Read 13.56MHz mifare card number, USB interface

CR20MW



• Read and write 13.56MHz mifare card, USB interface

CR10E



• Read 125K proximity card number, USB interface

CR10M



• Read 13.56MHz mifare card number, USB interface

CR10MW



• Read and write 13.56MHz mifare card, USB interface

