

ZKBiosecurity – Set device Status in/out


This setting is for the correct state on your reports. If it is check- in or Check-out.

You need to set the **State/Status** of the device to be either In/Out (Entry/Exit)

This is applicable on standalone devices and not InBio controllers.

Device > Device > Device

Select your device by tick the tick box and click on Setup Tab and select the **Set device in/out status**



Select is the device and entry or out status

Click on OK

