


ZKBiosecurity – How to modify your password on ZKBioSecurity


Following are steps to take when you do change your ZKBiosecurity Password

You can modify the login password (**PERSONAL INFORMATION**)

Click on the logo in front of the admin This  admin button is on the right-hand top corner.

Tick (**Reset Password**) box to modify the password

NB: Both superuser and the new users are created by the superuser (the default password for the new users is 111111). The user name is not case-insensitive, but the password is case-sensitive.



Personal Information	
Username*	admin <small>Username should be composed between 1-30 characters and in letters, numbers, or symbols (@, !, !, +, !, !).</small>
Reset Password	<input checked="" type="checkbox"/>
Multiple Login	<input type="checkbox"/>
Maximum Number	<input type="text"/> <small>Limit multiple login for the same account</small>
Superuser State	<input checked="" type="checkbox"/>
Role	<input type="text"/>
Auth Department	<input type="text"/> <small>If you don't select department you will not have full departmental permission.</small>
Authorize Area	<input type="text"/> <small>If you don't select zone you will not have full zone permission.</small>
Email	jolene.huang@zkteco.com
First Name	admin
Last Name	<input type="text"/>
Fingerprint	Register 0